

Title	Drawing Number
INSTRUCTION GUIDE FOR DTT-16-01	0425-038-0000
	OCT 1 1 2000
Revisions	

Revisions						
Sym	Description	Date	Approved			
NC	New Release per E.O. P16800	10-6-00	ROR			

1. WIRE PREPARATION

Prior to crimping contacts, wire must be stripped to a length of .175" \pm .025" [4.45 \pm 0.64]. Wire should have no insulation tearing or stretching and no conductor strands missing or damaged.

2. **CONTACT LOADING**

Cycle handles to release ratchet and fully open crimp jaws. Insert contact in cavity recommended for wire size. Adjust alignment and width of crimp wings if necessary to insure capture by crimp jaws.

Contacts may have sharp edges. Use finger protection to avoid cuts. Do not place fingers in tool areas which may pinch during crimp cycle. Use safety glasses to avoid eye injury.

3. HAND-CRIMP CYCLE

Close crimp tool until full-cycle ratchet control releases.

4. CONTACT REMOVAL

After completing the crimp cycle, open jaws fully. Remove crimped contact.

5. **MAINTENANCE**

To ensure correct functioning, maintenance must be performed on a regular basis. This includes: Lubrication of moving parts.

Removal of debris from jaw areas.

Visual inspection for loose hardware, broken or missing parts.

6. RECOMMENDED CAVITY FOR WIRE GAUGE AND INSULATION TYPES

Use this chart to insure best crimp results with Deutsch stamped and formed contacts 106*-16-01**, 106*-16-06**, 106*-16-07**, 106*-16-09**:

NOTE: when * = 0, P/N is PIN contact; when * = 2, P/N is SOCKET contact ** = PLATING CODE; see individual contact Envelope Drawings for available types.

Cavity	METRIC Wire Sizes	AWG Insulation Types
C	0.5 mm ²	
D	0.75 mm ²	
D		18 TXL, 18 GXL, or 18 SXL

Revision Letter:	NC	Engineering Order Number:	P16800	Page	1	of	2
	210	5	1 10000	1	1	٠.	2



DEUTSCH

INDUSTRIAL PRODUCTS DIVISION

3850 Industrial Avenue • Hemet, CA 92545

Title
INSTRUCTION GUIDE FOR DTT-16-01

Drawing Number 0425-038-0000

